


TYPE	OMSCHRIJVING/DESCRIPTION
Yn0	<p data-bbox="491 376 1034 443">aansluitschema 3 - fase spaartransformator connection diagram 3 - phase autotransformer</p> 

Step Up autotransformer :  
 Input voltage: a1 - b1 - c1 (- 0)  
 Output voltage: a2 - b2 - c2 (- 0)

Step Down autotransformer :  
 Input voltage: a2 - b2 - c2 (- 0)  
 Output voltage: a1 - b1 - c1 (- 0)

